

A320-Family Checklist

COCKPIT PREPARATION

BATTERIES BOTH ON
 EXT. POWER ON
 NAV LIGHTS ON
 IRS/ADIRS NAV/ALIGN
 ENG MASTER BOTH OFF
 ENG MODE SELECTOR NORM
 GEAR LEVER DOWN
 PARKING BRAKE OFF
 FLAPS POS
 SPEED BRAKES RETR
 THRUST LEVERS IDLE
 TRANSPONDER STBY
 RADIO CTRL PANEL ON
 ECAM RECAL CHECK
 FLIGHT DIRECTOR ON
 EMERGENCY LIGHTS ARM
 NO SMOKING ON
 ENG ANTI-ICE OFF
 PROBE WINDOW HEAT AUTO
 AIR CONDITION CHECK
 VENTILATION PANEL CHECK
 ELECTRIC PANEL CHECK
 FUEL PUMPS ON
 HYDRAULICS CHECK
 ACCU BRAKE PRESS SET
 GROUND PROXIMITY WARNING SYSTEM ON
 ELECTRONIC FLIGHT CONTROL SYSTEM ... ON
 EMERGENCY EQUIPMENT CHECK

BEFORE START

WINDOWS / DOORS CLOSED/LOCKED
 APU START
 APU BLEED ON
 EXT. POWER DISCONNECTED/OFF
 CABIN SIGNS ON
 PARKING BRAKES ON
 QNH SET
 BEACON LIGHTS ON

START / PUSHBACK

GROUND READY
 ENG MODE SELECTOR IGN
 ENG MASTER 2 ON
 ENG MASTER 1 ON
 PARKING BREAK ON
 GROUND CONFIRM GOOD START CHECK

AFTER START

ENG MODE SELECTOR NORMAL
 APU BLEED OFF
 APU MASTER OFF
 SPOILERS ARM
 RUDER TRIM CHECK 0
 PITCH TRIM SET
 FLIGHT CONTROLS CHECK
 FLAPS SET T/O
 ANTI ICE OFF
 ECAM DOOR PAGE CHECK
 HAND SIGNAL CHECK



TAXI FOR DEPARTURE

NOSE LIGHT TAXI
 MANUAL BRAKES CHECK
 BRAKE TEMP CHECK <150°
 BRAKE FANS OFF
 AUTO-BRAKES MAX
 TAKEOFF-DATA SET/REVIEW
 T/O-CONFIG CHECK NO BLUE



BEFORE TAKEOFF

BRAKE TEMP CHECK <150°
 BRAKE FANS OFF
 ENG MODE SELECTOR NORMAL
 TCAS TA/RA TILT ABV
 TRANSPONDER C
 EXT. LIGHTS ON
 CABIN CHECKED
 SLIDING TABLES STOWED



AFTER TAKEOFF

LANDING GEAR UP
 NAV ON PFD CHECK
 AUTOPILOT 1/2 ON
 TAXI LIGHT OFF
 SPOILERS DISARM
 THRUST LEVERS LVR CLB
 FLAPS UP
 SPEED ≤ 250KTS
 ENG PACKS BOTH ON
 ANTI-ICE AS RQRD
 TCAS CHECK
 ALTIMETER STD WHEN TA



10.000FT

LIGHTS OFF
 CABIN SIGNS AS RQRD



DESCENT PREPARATION

CABIN SIGNS ON
 ANTI-ICE AS RQRD
 LANDING INFO RECEIVED
 ECAM APPR INFO SET
 BARO RADIO SET
 FMA CHECK RADAR TILT BLW



APPROACH

LS ON
 ECAM STATUS CHECK
 SLIDING TABLES STOWED
 CABIN SIGNS CHECK
 NAV ACCURACY CHECK
 ALTIMETER AS RQRD
 EXT. LIGHTS ON



LANDING

TAXI LIGHT SET T.O.
 GO AROUND ALT SET
 GEAR DOWN
 SPOILERS ARM
 AUTO-BRAKES MED
 FLAPS LANDING
 LANDING MEMO NO BLUE



AFTER LANDING

SPOILERS RETRACT
 FLAPS RETRACT
 TCAS STBY
 TRANSPONDER STBY
 BRAKE TEMP CHECK <300°
 BRAKE FAN AS RQRD
 APU START START
 EXT. LIGHTS OFF
 ANTI-ICE AS RQRD



PARKING / SHUT DOWN

ENG MASTER 1/2 OFF
 PARKING BRAKES..... OFF WHEN ON CHOCKS
 CABIN SIGNS OFF
 BEACON LIGHTS OFF
 ANTI-ICE OFF
 FUEL PUMPS OFF
 APU AS RQRD
 EXT. POWER AS RQRD



SECURE

ADIRS OFF
 EXT POWER OFF
 GEN ON
 APU OFF
 EMERGENCY LIGHTS OFF
 BATTERIES BOTH OFF